



Nelson™ Bubble Lamps Care and Maintenance

With regular care and maintenance, your Herman Miller furniture will provide years of superior performance and satisfaction. To maintain the finish quality of your Herman Miller product, please follow the cleaning procedures provided below.

Use with up to 150 watt bulb for all sizes of Nelson Bubble Lamps except Small Saucer and Small Saucer Sconce. For the Small Saucer and Small Saucer Sconce, use with up to 60 watt bulb. Light bulb not included. Hardwiring required. The Half Nelson Table Lamp use with up to 40 watt bulb, not included.

Pendant Lamps

Lamp Shade

Plastic Polymer

Normal Cleaning

Use a feather duster, a clean soft white cloth, or vacuum with a clean soft brush attachment as needed.

For stubborn stains, clean the surface using a clean soft white absorbent cloth with a solution of mild soap and warm water.

Wipe down surfaces with the damp cloth and dry with a clean soft white cloth.

Make sure cleaning materials are free of grit and other foreign materials.

Avoid using glass cleaners, abrasive cleaning compounds, ammonia, or bleach; they may damage the surface of the plastic and result in discoloration.



Materials

Brushed Nickel Trim

Coated Metal

Normal Cleaning

Wash coated metal surfaces with a clean soft cloth soaked in detergent and warm water; rinse thoroughly and dry.

Remove scuff marks with pre-softened paste wax, following the instructions on the label.

After polishing, apply a pre-softened automotive paste wax to restore original sheen.

Do not use abrasive, acid, alcohol-based, or solvent-based cleaners; they may damage the finish.

Floor Lamps

Lamp Shade

Plastic Polymer

Normal Cleaning

Use a feather duster, a clean soft white cloth, or vacuum with a clean soft brush attachment as needed.

For stubborn stains, clean the surface using a clean soft white absorbent cloth with a solution of mild soap and warm water.

Wipe down surfaces with the damp cloth and dry with a clean soft white cloth.

Make sure cleaning materials are free of grit and other foreign materials.

Avoid using glass cleaners, abrasive cleaning compounds, ammonia, or bleach; they may damage the surface of the plastic and result in discoloration.

Brushed Nickel Trim and Base

Coated Metal

Normal Cleaning

Wash coated metal surfaces with a clean soft cloth soaked in detergent and warm water; rinse thoroughly and dry.

Remove scuff marks with pre-softened paste wax, following the instructions on the label.

After polishing, apply a pre-softened automotive paste wax to restore original sheen.

Do not use abrasive, acid, alcohol-based, or solvent-based cleaners; they may damage the finish.

Half Nelson Table Lamp

Lamp

Aluminum Coated Metal

Normal Cleaning

Wash coated metal surfaces with a clean soft cloth soaked in detergent and warm water; rinse thoroughly and dry.

Do not use abrasive, acid, alcohol-based, or solvent-based cleaners; they may damage the finish.

Table Lamps

Lamp Shade

Plastic Polymer

Normal Cleaning

Use a feather duster, a clean soft white cloth, or vacuum with a clean soft brush attachment as needed.

For stubborn stains, clean the surface using a clean soft white absorbent cloth with a solution of mild soap and warm water.

Wipe down surfaces with the damp cloth and dry with a clean soft white cloth.

Make sure cleaning materials are free of grit and other foreign materials.

Avoid using glass cleaners, abrasive cleaning compounds, ammonia, or bleach; they may damage the surface of the plastic and result in discoloration.

Brushed Nickel Trim and Base

Coated Metal

Normal Cleaning

Wash coated metal surfaces with a clean soft cloth soaked in detergent and warm water; rinse thoroughly and dry.

Remove scuff marks with pre-softened paste wax, following the instructions on the label.

After polishing, apply a pre-softened automotive paste wax to restore original sheen.

Do not use abrasive, acid, alcohol-based, or solvent-based cleaners; they may damage the finish.

Materials

Cover

Walnut

Normal Cleaning

Dust with a slightly damp, soft, lint-free cloth.

Wipe dry with a dry, soft cloth in the direction of the wood grain.

Once a Month

Clean the surface with a clean soft cloth dampened with a quality cleaner formulated for wood furniture.

Wipe the surface in the direction of the wood grain to remove dirt and fingerprints.

Wipe dry with a clean, dry cloth.

Twice a Year

Apply a good quality furniture polish with a soft cloth.

Do not use aerosol-powered cleaners or polishes.

Also, do not use polishes containing waxes or abrasives, or polishes that are oil based.

Minor Repair of water rings, stains, and scratches

Rub the surface lightly in the direction of the wood grain using No. 000 steel wool.

Apply a scratch-removing polish with a color and value that simulates the veneer.

If the scratches are deep, consult a professional furniture refinisher.

Wall Sconce Lamps

Lamp Shade

Plastic Polymer

Normal Cleaning

Use a feather duster, a clean soft white cloth, or vacuum with a clean soft brush attachment as needed.

For stubborn stains, clean the surface using a clean soft white absorbent cloth with a solution of mild soap and warm water.

Wipe down surfaces with the damp cloth and dry with a clean soft white cloth.

Make sure cleaning materials are free of grit and other foreign materials.

Avoid using glass cleaners, abrasive cleaning compounds, ammonia, or bleach; they may damage the surface of the plastic and result in discoloration.

Brushed Nickel Trim

Coated Metal

Normal Cleaning

Wash coated metal surfaces with a clean soft cloth soaked in detergent and warm water; rinse thoroughly and dry.

Remove scuff marks with pre-softened paste wax, following the instructions on the label.

After polishing, apply a pre-softened automotive paste wax to restore original sheen.

Do not use abrasive, acid, alcohol-based, or solvent-based cleaners; they may damage the finish.

Wall Mount

Walnut

Normal Cleaning

Dust with a slightly damp, soft, lint-free cloth.

Wipe dry with a dry, soft cloth in the direction of the wood grain.

Once a Month

Clean the surface with a clean soft cloth dampened with a quality cleaner formulated for wood furniture.

Wipe the surface in the direction of the wood grain to remove dirt and fingerprints.

Wipe dry with a clean, dry cloth.

Materials

Twice a Year

Apply a good quality furniture polish with a soft cloth.

Do not use aerosol-powered cleaners or polishes.

Also, do not use polishes containing waxes or abrasives, or polishes that are oil based.

Minor repair of water rings, stains, and scratches

Rub the surface lightly in the direction of the wood grain using No. 000 steel wool.

Apply a scratch-removing polish with a color and value that simulates the veneer.

If the scratches are deep, consult a professional furniture refinisher.

June 2017

© 2017 Herman Miller, Inc., Zeeland, Michigan

©  HermanMiller are among the registered trademarks of Herman Miller, Inc.

™ Nelson is among the trademarks of Herman Miller, Inc.